




BL - 40
BOARD




3 WIRE REMOTE

BL-40 REMOTE SWITCH DUAL THERM ONLY (TYPICAL HEATER)

1. SET POOL THERMOSTAT TO DESIRED TEMP.
 2. SET SPA THERMOSTAT TO HOT.
 3. BL-40 WILL CONTROL THE SPA TEMP ONLY.
- POOL THERMOSTAT IN HEATER WILL CONTROL POOL TEMP.



POOL/OFF/SPA
THERMOSTAT
SELECT SWITCH



FRONT PANEL
POOL/OFF/SPA
THERMOSTAT
SELECT SWITCH